

New Controls




Aëromatic is proud to welcome an all-new range of controls into its product line. These simple and easy-to-use controls allow you to loop a variety of modes at the push of a button. Each control fits inside any 2x4 service box and comes with a retaining screw and white deco wall plate.

Mode Control (Product #611230)

Function: Provides the ventilation unit with 4 modes of operation:

- Circulation mode
- Low-speed exterior exchange mode
- High-speed exterior exchange mode
- Stop mode (when the lights are off)


Hook-up: Colour-coded, 4-conductor wire provides a direct hook-up to the ventilation unit's control section. 



Speed Control (Product #611229)

Function: Provides the ventilation unit with 4 modes of operation:

- Intermittent mode; successive cycles, low-speed 20-min exchange, 40-min stop mode or circulation**
- Low-speed exterior exchange mode
- High-speed exterior exchange mode
- Stop mode or circulation ** (when the lights are off)

Hook-up: Colour-coded, 4-conductor wire provides a direct hook-up to the ventilation unit's control section. 

** Aëromatic 7260 and 7290, stop.


** Aëromatic 7200, 7210, 7250, 8230-5 and 8260-5, low-speed circulation.



20-40-60 Timer (Product #611228)

Function: Provides the ventilation unit with high-speed exterior exchange for the following durations:

- 20 minutes
- 40 minutes
- 60 minutes

Hook-up: Colour-coded, 3-conductor wire provides a direct hook-up to the ventilation unit's timer section . Four wires are required for model numbers 7200, 7210, 7250, 8230-5 and 8260-5.

